

F&F Filipowski L.P. Konstantynowska 79/81, 95-200 Pabianice, POLAND phone/fax (+48 42) 215 23 83 / (+48 42) 227 09 71 www.fif.com.pl: e-mail: biuro@fif.com.pl

DMV-1

Digital voltage indicator,

1-phase



Do not dispose of this device in the trash along with other waste! According to the Law on Waste, electro coming from households free of charge and can give any amoure of the test point of collection, as well as to store the occasion of the purchase many properties. The properties of the propert




Purpose

The DMV-1 voltage indicator is used for continuous reading of 1-phase mains voltage.

Functioning

The DMV-1 indicator with measurement system shows the actual value of the voltages in the phase.


Front description



Mounting

- 1. Switch off the power supply.
- Connect the indicator directly to the mains according to the connection diagram.
- 3. Switch on power supply.

Wiring diagram



- L power supply 6
- N power supply

Technical data

power supply 100÷300 V AC
supply frequency 45÷55 Hz
indication range 100÷300 V
display (for 1 phase) 3×digital LED 10×6 mm
power consumption 4 W

terminal 2.5 mm² screw terminals (cord) 4.0 mm² screw terminals (wire)

tightening torque 0.5 Nm working temperature -20÷50°C dimensions 3 modules (52.5 mm) mounting on TH-35 rail ingress protection 1P20

Warranty

The F&F products are covered by a warranty of the 24 months from the date of purchase. Effective only with proof of purchase. Contact your dealer or directly with us.

CE declaration

F&F Filipowski L.P. declares that the device is in conformity with the essential requirements of The Low Voltage Directive (LVD) 2014/35/EU and the Electromagnetic Compatibility (EMC) Directive 2014/30/UE.

The CE Declaration of Conformity, along with the references to the standards in relation to which conformity is declared, can be found at www.fif.com.pl on the product page 40619

E240619 - 4 -